

# INDASH by PANAVISE®

75107-316

Page 1 of 1

## MOUNTING LOCATION:

Left side of Air Vent VL

## TOOLS REQUIRED:

Dash Tool, Hook Tool  
7mm-(9/32) Socket Driver  
Phillips Screwdriver

## PARTS INCLUDED:

(1) S75107-316 (1) S75001

(2) 8-32 Acorn nuts

## MOBILE DEVICE & MEDIA MOUNT

### INSTALLATION INSTRUCTIONS

MAKE: FORD

MODELS & YEARS:

F-150 2015-2020

F-250, 350, 450, 550 Super Duty 17-20

Expedition 2017-2020

(Vent Side Mount)

## \*\* ADVISEMENT \*\*

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: With Dash tool remove the speaker cover bezel on top of the dash. Pry on the sides of the cover to release (4) clips. Set aside.

STEP #2: With 9/32 (7mm) socket driver, remove the (2) screws in front of the speaker. Using the Dash Tool, pry up on a side of the top of the dash tray bezel to release (1) clip. Continue along the front of the bezel releasing (2) more clips. Lift bezel off and set aside.

STEP #3: With 9/32 socket driver remove the (2) top screws that hold the radio bezel in place. With your hands pull the radio bezel from the top to release (2) clips. Continue down the bezel sides to release (2) more clips. With Dash or Hook Tool assist, pull out on the bottom of the bezel sides to release (1) clip on each side. Pull bezel off and move it to the side.

STEP #4: With 9/32 socket driver remove the (2) lower right radio/display screws. Slide the InDash Mount bottom piece in between the display/radio and air vent. Replace the screws making sure the mount is in place against the vent side.

STEP#5: Optional: With dremel, file, or edge cutters, remove 1/8" of the bezel edge that fits into the U-groove channel. See picture with location of cut. Test replace the radio bezel starting from the bottom. See how fit allows the dash pieces to line up. When fit is ok, replace all parts in reverse order.

STEP#6: Install the InDash Mount Top (75001) with 5/16" socket / wrench.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Top speaker cover bezel



Front of speaker screw location



Screws to remove radio bezel



InDash Installed



Bottom Part Installed



See Marked Cutout Location



09-22-2020

There may be recent updates to this Instruction Sheet, please visit our website [www.panavise.com](http://www.panavise.com) or contact PanaVise Products, Inc. for the latest revision as well as the most complete up-to-date PanaVise InDash Applications at 7540 Colbert Dr., Reno, NV, Phone: 800.759.7535, 775.850.2900, Fax: 800.395.8002, [www.panavise.com](http://www.panavise.com). © 2018 PanaVise Products, Inc.