

# INDASH by PANAVISE®

751072713

Page 1 of 1

**MOUNTING LOCATION:**  
Right side of Climate Control CR

CELL PHONE & MEDIA MOUNT  
INSTALLATION INSTRUCTIONS

**\*\* ADVISEMENT \*\***

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

**TOOLS REQUIRED:**

Dash Tool, Hook Tool  
9/32 or 7mm Socket Driver

PART#: 751072713

MFG: FORD

**HARDWARE INCLUDED:**

(1) S751072713 Mount, (1) 75001 Top  
(2) 8-32 Acorn nuts

MODELS & YEARS:

**FORD- Fusion 2013-2018**

STEP #1: With Dash tool remove the trim bezel that surrounds the shifter.

STEP #2: Then remove the 1/2 moon bezel at the back of the shifter console, lifting to release and set aside

STEP #3: Remove the trim bezel that goes around the top of the radio and down to the sides of the console.

STEP #4: With 7mm socket driver, remove the screw that is at the lower right side of the climate control. Place InDash by PanaVise Mount over the screw hole making sure the mount rests flush on the climate control. Tighten the screw.

STEP #4: Replace bezels in reverse order.

STEP #5: Install top piece of mount with the (2) Acorn nuts and the 5/16" socket driver.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Shifter Bezel removed



1/2 Moon Bezel removed



InDash installed showing location



InDash installed showing screw location



InDash bottom installed



Radio Trim Bezel removed

02-06-18

