

INDASH by PANAVISE®

751102815

Page 1 of 1

MOUNTING LOCATION:

Above Radio Display P U

TOOLS REQUIRED:

Phillips Screwdriver

PARTS INCLUDED:

(1)S751102815

(1)#8x9/16 Needle Pt.Screw

MOBILE DEVICE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: **751102815**

MFG: **CHEVY / GMC**

MODELS & YEARS:

CHEVY-Tahoe/Surburban 15-18

GMC- Yukon 15-18

(Without Moving Display Screen)

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: With hands lift off the dash bezel above the Radio Display Screen. there are (3) clips that hold it in place. Set aside.

STEP #2: Place the mount rectangle hole over the center clip. Push back on the lower part of the mount to set the mount behind the (2) ribs.

STEP #3: Install the (1) Phillips head screw with screwdriver while pushing down on the mount to seat it in place.

STEP #4: .Replace the top dash bezel.



InDash installed showing location of clip and screw

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PanaVise Mount



InDash installed showing location



InDash installed showing location of clip and screw