

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Radio bezel removal showing (10) clips for removal of radio bezel.



InDash showing (2) mounting bolts placement.

MOUNTING LOCATION:

Right side of Radio JR

TOOLS REQUIRED:

Flat Dash Tool

10mm Socket Driver

PARTS INCLUDED:

(1) S7137-916 Mount

(1) S775001Mount Top

CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#:75137-916

MFG: TOYOTA

MODELS & YEARS:

Tacoma 2016-2019

STEP #1: With your hands and Flat Dash Tool assist, remove the bezel that surrounds the radio and includes the center air vents. Begin by pulling from the right side of the bezel. Pull to release a total of (10) clips. Set bezel aside.

STEP #2: With 10mm socket driver remove the (2) right radio bolts.

STEP #3: Place the InDash Mount onto the right side of the radio, matching up the joggle of the radio face with the joggle of the InDash Mount. Line up the legs of legs of th InDash with the bolt holes, and tighten the bolts finger tight. Check the alignment of the joggles, and tighten the bolts.

STEP #4: Replace the bezel starting by placing the right side of the bezel partially over the right air vent. Push to snap the rest (left side) of the bezel in place. It will be tight

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



InDash installed showing location



06-20-18