

MOUNTING LOCATION:

Right side of dash cavity KR

TOOLS REQUIRED:

T20 Torx driver
T25 Torx driver

HARDWARE INCLUDED:

None

**CELL PHONE & MEDIA MOUNT
INSTALLATION INSTRUCTIONS**

PART#:75141-199

MFG: FREIGHTLINER

MODELS & YEARS:

Century Class 1997-2010

Columbia 1999-2010

Coronado132 02-19, Argosy 02-07

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDashMounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

- STEP #1** Remove the trim panel that surrounds the radio by pulling from the right side of the panel to release two clips that secure the end of the trim panel. Loosen the trim panel just enough to expose the Torx screw which holds the end trim piece in place. (The end trim piece is located to the right and just above the radio.) Using the Torx driver, remove the Torx screw and set aside. Remove end trim piece by grasping with hands and pulling toward you to release one clip on the top of the end trim piece. Set trim aside.
- STEP #2** Remove two Torx screws that hold the wood grain trim panel. Place InDash Mount over the holes and reinstall the screws to secure InDash.
- STEP #3** Install the end trim piece back in place. Install the screw behind lower trim panel. Install the lower trim panel that surrounds the radio. Attach phone holder to InDash.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW PANAVISE INDASH MOUNT.



08-06-18