

### MOUNTING LOCATION:

Right side of dash cavity

### TOOLS REQUIRED:

Flat screwdriver

T-20 Torx driver

Large pliers or Channellocks

### HARDWARE INCLUDED:

None

### CELL PHONE & MEDIA MOUNT

### INSTALLATION INSTRUCTIONS

PART#: **75142-302**

MFG: **KENWORTH**

MODELS & YEARS:

**T170, T270 09-14**

**T300, T370, T470 09-2015**

**T600, T800, W900 2002-2005**

### \*\* ADVISEMENT \*\*

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

**STEP #1:** With T-20 Torx driver or Flat screwdriver remove the (2) screws that hold the dash panel on that is just left of the glove box. Pull the panel back enough to install the InDash by PanaVise Mount.

**STEP #2:** Place the InDash by PanaVise Mount over the top right hole on the dash cavity. Temporarily Install the screw to hold the mount in place. Align InDash by PanaVise Mount to the side of the dash panel. With Pliers crimp down the (2) tabs to hold the mount in place.

**STEP #3:** Holding onto the mount, unscrew the screw and put dash panel back in place, and reinstall the (2) screws. Attach phone holder or device to InDash by PanaVise Mount.



Mounting Screw Location



INSTALLATION IS NOW COMPLETE  
ENJOY YOUR NEW INDASH by PANAVISE MOUNT



T600, 660, 800, W900, C500  
Final Installation Picture



K100C, T170, T270, T370, T300  
Final Installation Picture



02-27-15